



Message From The Founders

First off we want to say thank you, and that we appreciate the faith you have in our brand to buy our product.

We started Tech Armor with the idea that we would bring high quality products to our customers at a price everyone can afford. We start with the best components available and combine that with support from the best team in the business, our valued Tech Armor Nation, and back it all with the industry best Tech Armor Lifetime Product Replacement Warranty.

If you are anything less than happy with our products, we want to know about it! Your feedback, good or bad, makes us a better brand and lets us serve you better, so please don't keep quiet. Email us at customersupport@techarmor.com. We will make sure you are 100% satisfied with your Tech Armor purchase or we will refund you.

Thank you for your business.

Joe and Eric
Co-Founders

INSTALLATION GUIDE

Check out our easy instructions and watch a short video to get the best installation for your new car mount.

techarmor.com/car-mounts



TECH ARMOR®

Universal Magnetic Car Mount

Suction Cup with Adjustable Angle

Package Includes:

Please verify you have the following parts:



Step 1: Mounting of Steel Plate

(Option 1) Mounting to back of Phone:

- a. Place Clear Protective Sticker (yellow removable backing) on to back of phone.
- b. Attach Steel Plate with 3M Adhesive on top of the Clear Protective Sticker being careful not to adhere directly to the phone for easy removal later and to prevent scratching of the back of your phone.

(Option 2) Mounting to inside of phone case

- a. You're welcome to use the 3M Adhesive plate and simply stick it to the inside of your case.
- b. OR, you have the option of using the other metal plate (without 3M adhesive backing) and simply place it inside of your phone case. Lay your case down flat and place the metal plate inside.
- c. Place Clear Protective Sticker (yellow removable backing) on your phone to prevent scratching of the back of your phone.
- d. Place your phone back in the case, while it is still laying flat on the table to prevent movement.



Step 2: Securing the Mounting Arm

- a. Clean the area where you will affix the Suction Cup Base and make sure that the target area is clean, dry and free of debris.
- b. Remove the protective layer from the Suction Cup Base to expose the adhesive.
- c. Firmly push the Suction Cup Base into place.
- d. Pull down the suction cup activation lever to firmly hold the Suction Cup Base in place.

(NOTE: THE ADHESIVE IS VERY STRONG AND MAY DAMAGE LEATHER, VINYL OR OTHER MATERIALS UPON REMOVAL. TECH ARMOR IS NOT RESPONSIBLE FOR DAMAGE THAT MAY OCCUR FROM THE ADHESIVE TO YOUR VEHICLE, FURNITURE OR OTHER PLACEMENT LOCATION)

Step 3: Adjusting the Magnetic Base

- a. Loosen the threaded Collar on the back of the Magnetic base (Turn Counter-Clockwise to loosen) until it is almost removed.
- b. Gently push Magnetic Base and loosened collar onto the ball joint of the Mounting Arm until you feel it snap into place.
- c. Tighten the collar with your fingers so it can still move but is tight. Do not use any tools to tighten the collar as you may over-tighten and strip the threads.

Step 3: Mounting Your Phone

Simply place your phone (or case) with the installed Steel Plate against the Magnetic Base and enjoy!

Please, ALWAYS use caution while driving and save the texts or emails until you've come to a complete stop!